



Technical efficiency





floor & more

Grease Out Caps

Degreasing cleaner

- Concentrated refill for sprays
- For food contact surfaces & cooker hoods
- Under the Occupational Exposure Limits (OEL - EU, FR, BE)



Product information:





Grease Out Caps



floor & more

Degreasing cleaner

DESCRIPTION

Degreasing cleaner for food contact surfaces, concentrated refill for sprays. The product quickly removes mineral and vegetable grease stains on washable surfaces. Also degreases hoods. Suitable for the cleaning of non-food-contact surfaces, billboards and modern surfaces.
Food contact approved.

METHOD

Spray on the surface to be cleaned. Scrub with a scrubbing brush. Rinse with clear water. Wipe with a well-wrung microfiber cloth.

USE

1. Rinse the spray before each refill.
2. Fill the spray with water. Do not fill to the top. Leave enough volume for the concentrate product to mix.
3. Screw the Caps completely on the spray, mix.
4. Remove the Caps and screw the spray head on.
5. After use, place the empty Caps into its cartridge for recycling.

WASTE MANAGEMENT

The manufacturer guarantees the complete recycling of empty Caps and their packaging. Consult your dealer for the return free of charge to the manufacturer.

TECHNICAL CHARACTERISTICS

- Fragrance: fruity
- Color: yellow
- Pure pH: 9,5 ± 0,5

STORAGE

Keep the product in its original closed packaging. Protect against freezing temperatures.

CONSERVATION

Best use within 2 weeks after dilution based on good storage conditions

ECOLOGICAL INFORMATION

- Biodegradable product (CE 648/2004)
- Packaging 100% recyclable

PACKAGING



| Packaging | Reference | EAN code |
|------------------|-----------|----------------|
| Carton 32x4 Caps | 2210873 | 05411283226585 |
| Carton 4x4 Caps | 2110978 | 05411283217897 |
| Starter kit | 9200130 | 05411283923019 |
| Empty spray | 9900385 | |

Date of last revision: 27-08-2018