



Technical efficiency



sharing our passion

Washglanz 40

Concentrated rinsing additive

- Accelerates the drying of the crockery
- Sparkling glassware and cutlery stain-free as of the first machine run
- Anti-foam surface-active agents improve the dishwasher's efficiency
- Suitable for any professional dishwasher
- Without coloring, fragrance-free
- Non allergenic



Product information:





Washglanz 40

Concentrated rinsing additive

DESCRIPTION

Acid rinsing product for the automatic dishwashing. Washglanz 40 allows the crockery to dry quickly without leaving a trace. It comes with an adapted electronic dosing system. Appropriate for any type of industrial dishwasher.

Food contact approved.

USE

- Sort the crockery and remove the scraps. Put the crockery into the machine. The product is automatically dosed in the machine by the dosing system.
- Replacing an empty can: turn off the crockery dishwasher. Turn off the Pollet doser if necessary. Wear safety goggles and gloves. Remove the product aspiration pipe from the empty can, with prudence. Introduce the aspiration pipe into the new can. Turn on the doser and the dishwasher. Restart the Pollet doser pump, if necessary.

DOSAGE

- 0,05% to 0,07% (0,5-0,7g/L), according to the water hardness.

TECHNICAL CHARACTERISTICS

- Color: colorless
- Pure pH: 2,25 ± 0,25

STORAGE

Keep the product in its original closed packaging.

ECOLOGICAL INFORMATION

- Biodegradable product (CE 648/2004)
- Packaging 100% recyclable

PACKAGING



Packaging	Reference	EAN code
10-liter can	4517423	5411283452342